EGISMOS

450nm, Blue Laser Module

Application

Industrial areas / Medical / Biochemical / Laser Tag
Property
Wavelength Range = 450nm (others optional)

Introduction

Egismos created high stability and quality laser modules that are successfully applied in aerospace, military industry, biochemistry, medicine etc.



Specifications(T=25°C)		
Items	Symbols	H834501D, H834505D, H8345010D, H8345030D
		H854501D, H854505D, H8545010D, H8545030D
Mode		PWM modulation
Modulation Frequency		10KHz
Wavelength	λ	450nm
Lens		Glass
Spot	D/R	Dot
Spot Size	D	<4x7mm at 10m
Diameter x Length	ΦxL	8X45 mm
Output Power	Po	<1mW, <5mW, <10mw, <30mw
Power Stability		<5%
Divergence Angle	mrad	<0.7
Operating Voltage(DC)	Vo	3V / 5V
CW Operating Current	l _o	220mA max
Operating Temperature	T _{case}	-10°C~+70°C
Storage Temperature	Ts	-40°C~+85°C
Housing Material		Aluminum
Mean time to failure		>8000 hrs



ismos 8mm Laser Module Series **Outline Dimensions** 45±0,5 145±5 32.5 øЗ 5±0.5 Ø8±0.05 UL 1007 AWG 26# RED/BLACK WIRE Spot size Define Intensity of a Gaussian Beam (w = 40mm, x = 30mm) 200 150 100 3d example of beam profile Example with 2d/3d and 2d slices and

2d example of beam profile



Dcc no: EG-QS-T-PM-ST-0007

Form no: EG-QR-T-QA-0003

Date:2019.05.23

-110

: K (MM)



The actual output power will between the range 2.5mW to 3.5mW, but once make sure the value, for example, $3mW\pm0.15mW$ or $3.2mW\pm0.16mW$ in the 25 \degree C temperature. Then the power stability represent 5%.

Spot size

The spot size defined as Gaussian beam. In optics, a Gaussian beam is a beam of electromagnetic radiation whose transverse electric field and intensity (irradiance) distributions are well approximated by Gaussian functions. Many lasers emit beams that approximate a Gaussian profile, in which case the laser is said to be operating on the fundamental transverse mode, or "TEM00 mode" of the laser's optical resonator. When refracted by a diffraction-limited lens, a Gaussian beam is transformed into another Gaussian beam (characterized by a different set of parameters), which explains why it is a convenient, widespread model in laser optics.

Mean time to failure (MTTF)

Mean time to failure (MTTF) is the length of time a device or other product is expected to last in operation. MTTF is one of many ways to evaluate the reliability of pieces of hardware or other technology. It's important to note, however, that the mean time to failure metrics provided by companies regarding specific products or components may not have been collected by running one unit continuously until failure. Instead, MTTF data is often collected by running many units, even many thousands of units, for a specific number of hours



EGISMOS Laser Safety

The light emitted from these devices has been set in accordance with IEC60825. However, staring into the beam, whether directly or indirectly, must be avoided.

Class I

The maximum permissible exposure(MPE) cannot be exceeded, it includes High-power lasers within an enclosure that prevents exposure to the radiation and that cannot be opened without shutting down the laser. For example, a continuous laser at 600nm can emit up to 0.39mW, but for shorter wavelengths, the maximum emission is lower.

Class II

"Caution", visible laser light less than 1.0mW. Considered eye safe, normal exposure to this type of beam will not cause permanent damage to the retina.

Class IIIA

"Danger", visible laser light between 1.0mW and 5.0mW. Considered eye safe with caution. Focusing of this light into the eye could cause some damage.

Class IIIB

"Danger", infrared(IR), and high power visible lasers considered dangerous to the retina if exposed. NB: it is important to note that while complying with the above classifications, unless otherwise stated. Our laser diode products are not certified and are designed solely for use in OEM products. The way in which device is used in the final product may alter its original design classification, and it is the responsibility of the OEM to ensure compliance with the relevant standards.

Specifications are subject to change without notice.





Dcc no: EG-QS-T-PM-ST-0007

Form no: EG-QR-T-QA-0003